

CNV232-485PW+

RS232 to RS422 / 485 converter. Can be powered from COM port control signals

FEATURES

- With CNV232-485PW + you get an RS485 or RS422 port on the PC
- Selecting RS422 or RS485 with DIL switches on the device
- Super compact with DB9 female and screw terminals
- Can be powered by external voltage from 9 - 12VDC / 500mA
- Operating temperature: -40 - + 85 ° C



Danbit A/S Schous plass 1 Oslo, N-0552
Norway



67 104 460



salg@danbit.dk

CNV232-485PW+

SPECIFICATIONS

Forsyning : Forsynes af RS232 porten



Danbit A/S Schous plass 1 Oslo, N-0552
Norway



67 104 460



salg@danbit.dk