

DIN5F-DIN6MM

AT keyboard can via the inverter connected to PS / 2  
on a PC

## FEATURES

Inverter AT keyboard PS2 (PS)



Danbit A/S Schous plass 1 Oslo, N-0552  
Norway



67 104 460



salg@danbit.dk