

CNV-USBB-RS232

USB printer connects to RS232 port - DB9 female to USB B, 1.8 meter cable. The converter is only for specific USB printers

FEATURES

- RS232 for USB printer adapter cable
- connect USB printer to PC com port
- automatic baud rate
- power supply included
- DB9 female and USB B
- Supply voltage: 5VDC 100mA
- GDI printers (without own emulation) are not supported
- See list of supported printers under Downloads



Danbit A/S Schous plass 1 Oslo, N-0552
Norway



67 104 460



salg@danbit.dk