

CNV-USB-RS485-4P

Restlager: converter, USB til 4 x RS232/485 FEATURES

4 x DB9, strømforsyning inkludert



Danbit A/S Schous plass 1 Oslo, N-0552
Norway



67 104 460



salg@danbit.dk